



UL branch circuit fuses (may also be used for supplemental protection)

Fuse class	Catalog symbol*	Amp range	Fuse blocks**	Fused switches**	DIN-Rail holders**	Inline holders**	Panel mount holders**	Open center blocks**	PCB fuseclip**	PCB holder**
Class CC	FNQ-R, KTK-R, LP-CC	up to 30	BCM603	CCP-_-30CC, CCPLP-_-30CC-_, OPM-1038RSW, RDF30CC-_-	CHCC, OPM-NG-SC3, OPM-1038R	HEY, HEZ	HPF-RR, HPS-RR	—	1A3400, 5956, 5960	—
Class CF	FCF, PVCF, TCF, WCF (690 V)	1 - 100	TCFH_N (600 V), TCFH_NW (690 V)	CCP-_-_CF (TCF and FCF only)	TCFH_N (600V), TCFH_NW (690V)	—	—	—	—	—
Class G	SC	1/2 - 15	BG301	—	—	HEG	HPG-EE, HPS-EE	—	5956, 5960	—
		20	BG302	CCPLP-_-20G-_-	—	HEH	HPS-JJ	—	—	
		25 - 30	BG303	—	HEC	HPS-FF				
		35 - 60	G30060	—	HEJ	—				
Class J	DFJ, LPJ, JKS,	up to 30	JM60030, JM60030-_MW_†, JP60030-3	RDF30J-_-COMP, RDF30J-_-	CH30J, JT(N)60030	—	—	11241-3	—	—
		35 - 60	JM60060, JM60060-_MW_†	RDF60J-_-COMP, RDF60J-_-	CH60J, JT(N)60060			11239-3		
		70 - 100	JM60100, JM60100-_MW_†	RDF100J-_-	—			1BS101, BH-0111		
		110 - 200	JM60200, JM60200-_MW_†	RDF200J-_-				—		
		250 - 400	JM60400, JM60400-_MW22, JM60400-_MW_†	RDF400J-_-	BH-3145					
		450 - 600	JM60600	RDF600J-_-	BH-3144					

* Refer to data sheets for applicable fuse voltage and interrupting ratings, agency information and other specifications.

** Fuse blocks and fused switches are available in a variety of pole and terminal configurations, and voltage and withstand ratings (SCCRs). Refer to data sheets for complete catalog numbers and specifications.

† This is a UL™ Listed power distribution fuse block, combining a fuse block and power distribution block into one unit.

Application engineering assistance

Technical assistance is available Monday - Friday, 7:00 a.m. - 5:00 p.m. Central time. Call toll-free 1-855-BUSSMANN (1-855-287-7626). Email: FuseTech@eaton.com.



UL branch circuit fuses (may also be used for supplemental protection)

Fuse class	Catalog symbol*	Amp range	Fuse blocks**	Fused switches**	DIN-Rail holders**	Inline holders**	Panel mount holders**	Open center blocks**	PCB fuseclip**	PCB holder**
Class H/K5 250 V	NON	up to 30	HM25030, HM25030-_MW_†	—	CH14	—	—	—	—	—
		35 - 60	HM25060, HM25060-_MW_†		11241-3, 11242-3					
		70 - 100	HM25100		—					
		110 - 200	HM25200		—					
		250 - 400	HM25400		—					
		450 - 600	HM25600		—					
Class H/K5 600 V	NOS	up to 30	HM60030, HM60030-_MW_†	—	—	—	—	11241-3, 11242-3	—	—
		35 - 60	HM60060, HM60060-_MW_†					11239-3, 11240-3		
		70 - 100	HM60100					—		
		110 - 200	HM60200					—		
		250 - 400	HM60400					—		
		450 - 600	HM60600					—		
Class L	KLU, KRP-C, KTU	601 - 800	51215 (1-pole), 51235 (3-pole)	RDF800L_	—	—	—	—	—	—
		801 - 1200	51215 (1-pole), 51235 (3-pole)	—						
		1350 - 6000	—	—						
Class RK1/RK5 250 V	FRN-R, KTN-R, KWN-R, LPN-RK	up to 30	RM25030, RM25030-_MW_†	—	—	—	—	—	—	—
		35 - 60	RM25060, RM25060-_MW_†							
		70 - 100	RM25100							
		110 - 200	RM25200							
		250 - 400	RM25400							
		450 - 600	RM25600							

* Refer to data sheets for applicable fuse voltage and interrupting ratings, agency information and other specifications.

** Fuse blocks and fused switches are available in a variety of pole and terminal configurations, and voltage and withstand ratings (SCCRs). Refer to data sheets for complete catalog numbers and specifications.

† This is a UL™ Listed power distribution fuse block, combining a fuse block and power distribution block into one unit.

Application engineering assistance

Technical assistance is available Monday - Friday, 7:00 a.m. - 5:00 p.m. Central time. Call toll-free 1-855-BUSSMANN (1-855-287-7626). Email: FuseTech@eaton.com.



UL branch circuit fuses (may also be used for supplemental protection)

Fuse class	Catalog symbol*	Amp range	Fuse blocks**	Fused switches**	DIN-Rail holders**	Inline holders**	Panel mount holders**	Open center blocks**	PCB fuseclip**	PCB holder**
Class RK1/RK5 600 V	FRS-R, KTS-R, KWS-R, LPS-RK	up to 30	RM60030, RM60030- _{MW} _†	—	—	—	—	—	—	—
		35 - 60	RM60060, RM60060- _{MW} _†							
		70 - 100	RM60100							
		110 - 200	RM60200							
		250 - 400	RM60400							
		450 - 600	RM60600							
300V Class T	JJN	up to 30	T30030	—	—	—	—	—	—	—
		35 - 60	T30060							
		70 - 100	T30100							
		110 - 200	T30200							
		250 - 400	T30400							
		450 - 600	T30600							
		601 - 800	—							
		801 - 1200	—							
600V Class T	JJS	up to 30	T60030	—	—	—	—	—	—	—
		35 - 60	T60060							
		70 - 100	T60100							
		110 - 200	T60200							
		250 - 400	T60400							
		450 - 600	T60600							
		601 - 800	—							
		601 - 800	—							

* Refer to data sheets for applicable fuse voltage and interrupting ratings, agency information and other specifications.

** Fuse blocks and fused switches are available in a variety of pole and terminal configurations, and voltage and withstand ratings (SCCRs). Refer to data sheets for complete catalog numbers and specifications.

† This is a UL™ Listed power distribution fuse block, combining a fuse block and power distribution block into one unit.

Application engineering assistance

Technical assistance is available Monday - Friday, 7:00 a.m. - 5:00 p.m. Central time. Call toll-free 1-855-BUSSMANN (1-855-287-7626). Email: FuseTech@eaton.com.



UL supplemental/midget fuses (for supplemental protection of equipment)

Fuse class	Catalog symbol*	Amp range	Fuse blocks**	Fused switches**	DIN-Rail holders**	Inline holders**	Panel mount holders**	Open center blocks**	PCB fuseclip**	PCB holder**
13/32" diameter by various length										
13/32 x 1-1/2"	AGU, BAF, FNM, FNO, KLM, KTK	up to 30	BMM603-_, 3743, 3835, 4421, 4515	CCP-_-30M CCPLP-_-30M-_ OPM-1038SW	CHM, NDNLF1-WH, NDNF1-WH, OPM-1038, OPM-NG-SM3	HEB, HEX	HPC-D, HPD, HPF, HPG, HPM, HPM-D, HPS2, HPS	3743, 4421, 4515	1A3400, 5956, 5960	—
"13/32 x 1-3/8"	BBS	up to 30	BMM603-__	—	—	HEH	HPS-L	4421, 4515	1A3400, 5956, 5960	—

* Refer to data sheets for applicable fuse voltage and interrupting ratings, agency information and other specifications.

** Fuse blocks and fused switches are available in a variety of pole and terminal configurations, and voltage and withstand ratings (SCCRs). Refer to data sheets for complete catalog numbers and specifications.

Application engineering assistance

Technical assistance is available Monday - Friday, 7:00 a.m. - 5:00 p.m. Central time. Call toll-free 1-855-BUSSMANN (1-855-287-7626). Email: FuseTech@eaton.com.



Electronic and PC board small dimension glass and ceramic tube fuses (for protecting electronic equipment and appliances)

Fuse class	Catalog symbol*	Amp range	Fuse blocks**	Fused switches**	DIN-Rail holders**	Inline holders**	Panel mount holders**	Open center blocks**	PCB fuseclip**	PCB holder**
5 mm diameter by various length										
5 x 15 mm	C515	125mA - 7	—	—	—	HHT	—	—	1A3399, 1A5018, 1A5601, 1A5602, HTC-200M, HTC-210M	—
	C517	3A only								
	C518	100mA - 5								
	C519	125mA - 5								
	C520	300mA - 5								
5 x 20 mm	S500	32mA - 10	—	—	F520	HHT	HTB, HTC-35M, HTC-40M HTC-55M, HTC-70M	—	1A3399, 1A5018, 1A5601, 1A5602, HTC-200M, HTC-210M	HTC-15M, HTC-45M, HTC-50M, HTC-60M, HTC-140M, HBH-M, HBV-M, HBW-M
	S501	50mA - 10								
	S505	500mA - 12								
	S505H	500mA - 10								
	S506	32mA - 15								
	GDA	50mA - 6.3								
	GDB	32mA - 16								
	GDC	32mA - 6.3								
	GMA	100mA - 15								
	GMC	50mA - 10								
	GMD	125mA - 4								

* Refer to data sheets for applicable fuse voltage and interrupting ratings, agency information and other specifications.

** Fuse blocks and fused switches are available in a variety of pole and terminal configurations, and voltage and withstand ratings (SCCRs). Refer to data sheets for complete catalog numbers and specifications.

Application engineering assistance

Technical assistance is available Monday - Friday, 7:00 a.m. - 5:00 p.m. Central time. Call toll-free 1-855-BUSSMANN (1-855-287-7626). Email: FuseTech@eaton.com.



Electronic and PC board small dimension glass and ceramic tube fuses (for protecting electronic equipment and appliances)

Fuse class	Catalog symbol*	Amp range	Fuse blocks**	Fused switches**	DIN-Rail holders**	Inline holders**	Panel mount holders**	Open center blocks**	PCB fuseclip**	PCB holder**
1/4" diameter by various length										
1/4 x 7/8"	AGW	1/4 - 30	—	—	—	HHB, HM, HR, HRK	HJL	—	1A1907, 1A1119, 1A1120, 1A3398, 1A4533, 1A4534, 5681, 5682	—
1/4 x 1"	AGX	1/4 - 30	3828	—	—	HHB, HM, HR, HRK	HJL	—	1A1907, 1A1119, 1A1120, 1A3398, 1A4533, 1A4534, 5681, 5682	—
1/4 x 1-1/4"	ABC	1/4 - 30	S-8000, S-8100, S-8200, S-8300 2499, 3828, 4393, 4406, 4505, 4520, 4574	—	NDNFD1, NDNLFD1	HFA, HFB, HFB10, HHB, HM, HR, HRK	HKP, HTB, HK, HLD	—	1A1907, 1A1119, 1A1120, 1A3398, 1A4533, 1A4534, 5681, 5682	HBH-I, HBV-I, HBW-I
	AGC	1/8 - 30								
	GBB	1 - 30								
	MDA	1/4 - 30								
	MDL	1/16 - 30								
	MDQ	1/100 - 15								

* Refer to data sheets for applicable fuse voltage and interrupting ratings, agency information and other specifications.

** Fuse blocks and fused switches are available in a variety of pole and terminal configurations, and voltage and withstand ratings (SCCRs). Refer to data sheets for complete catalog numbers and specifications.

Eaton and Bussmann are valuable trademarks of Eaton in the US and other countries. You are not permitted to use the Eaton trademarks without prior written consent of Eaton. UL is a registered trademark of the Underwriters Laboratories, Inc.

Application engineering assistance

Technical assistance is available Monday - Friday, 7:00 a.m. - 5:00 p.m. Central time. Call toll-free 1-855-BUSSMANN (1-855-287-7626). Email: FuseTech@eaton.com.